

## **Amazone Instructions**

## www.rotomudscrapers.com



Angle bracket is installed with 1 1/4" x 1/2" carriage bolt.

Adjust the scraper so that it has approximately 1/8" space between the tire.

Adjust the scraper distance from the tire here with the ubolt provided.

Replace original bolt with new bolt provided.



Adjust the scraper here to keep it 18 MM away form the edge of the tire.

Angle bracket is installed with 1" x 1/2" carriage bolt.