



CIH 700 Concord Style Instructions

www.rotomudscrapers.com

Mount base bracket here and replace original bolt with 1/2 x 4.5" bolt provided

7/16 x 1.25" carriage bolts fasten curved C channel to the base bracket



Angle bracket can be adjusted for front and back mounting

Adjust the scraper so that it has 5/8" between the rubber