



Gang Packer Instructions

www.rotomudscrapers.com

*Our 2016 models have a seal kit on top of disc.
Please see Disk assembly instructions.*

Mount the zinc bracket with the two 1/2" carriage bolts provided.

Adjust the scraper left and right in the slot. Keep the edge of the scraper at least 3/4" to 1" from the edge of the tire. The more offset, the better the performance.

Mount the scraper onto the 2" square tube behind the packer wheels with the two ubolts provided.

Use the zinc plate as backing for more strength.

Slide the scraper up and down in these slots. Try to position the scraper so that it is approximately 1/8" from the closest spot of the tire when the tire is turned. The tires are not all perfectly round, therefore be careful not to have it touch a high point of the tire.

Keep the scraper 3/4" to 1" from the edge of the tire.

