

Pillar 2 Instructions

www.rotomudscrapers.com



Angle bracket is installed with 1 1/4" x 1/2" carriage bolt.

Adjust the scraper so that it has approximately 1/8" space between the tire.

Insert 7/16" bolt here to keep the bracket from spinning



Use a straight edge (Carpenters Square) and adjust the scraper in the slot so that the scraper is at 1/2" minimum from the side of the tire.

The zinc angle bracket with the slot is fastened to the "C" Channel with a 1.25" carriage bolt and nut.