



Salford Instructions

www.rotomudscrapers.com

1/8 Inch between tire and scraper



Adjust the scraper distance from tire with the 3/8" bolts and nuts here

Fasten base bracket with wheel bolt and nut



Slide the scraper in the slot so that it is offset minimum 1/2" from the edge of the tire on a 4" wide tire like this one

The zinc angle bracket with the slot is fastened to the "C" Channel with a 1.25" carriage bolt and nut