



Scraper Placement

www.rotomudscrapers.com

NEVER TRY TO CENTER THE SCRAPER ON THE TIRE



Mount the upper bracket with the two 3/8 carriage bolts loosely before mounting the lower bracket on the seeder.

Angle bracket installed with 1" x 1/2" carriage bolt.



Use a straight edge (Carpenters Square) and adjust the bolt so the scraper is 3/4" minimum from the side of tire.

Adjust the scraper approximately 1/8" space between the tire.

NEVER TRY TO CENTER THE SCRAPER ON THE TIRE