


## **Crosslot Instructions**

## www.rotomudscrapers.com



2016 Model has the bearing on the inside of the disk. See Disc assembly instructions